

**Halogen Bulb Worklamps generate heat.** Please ensure these lamps are on for no more than 2 hours continuous use. Then switch off and allow to cool.

## L17 HALOGEN BULB WORK LAMPS


**L17.00** Flood.  
**L17.100** Spot.

**L17**  
**12V ONLY**

Lamps supplied less bulb.  
For LED worklamps please see page 83.

### Spare Parts

18549.00 Lens Assembly, Flood.  
18549.01 Lens Assembly, Spot.  
12V Bulb H453.  
24V Bulb H460.



## L18 HALOGEN BULB (X2) WORK LAMP


**L18.00** Duo power flood.  
**L18.100** Duo power spot.

**L18**  
**12V OR 24V**

Lamps supplied less bulb.  
For LED worklamps please see page 83.

### Spare Parts

18550.00 Lens Assembly, Flood.  
18550.01 Lens Assembly, Spot.  
12V Bulbs 2 X H453.  
24V Bulbs 2 X H460.



## L20 HALOGEN BULB WORK LAMP

**L20.00** Flood.  
**L20.100** Spot. Side Mounting.

**L20**  
**12V OR 24V**

Lamps supplied less bulb.  
For LED worklamps please see page 83.

### Spare Parts

18551.00 Lens Assembly Flood.  
18551.01 Lens Assembly Spot.  
12V Bulb H453.  
24V Bulb H460.

